

Sensors & Applications
Medical Technology &
Production



More Precision



About us

Micro-Epsilon is a medium-sized company group and a leader in measurement technology. For more than 50 years, we have delivered top performance by offering unsurpassed solutions when it comes to precise measurement and testing. Our product portfolio ranges from sensors for non-contact displacement and distance measurements, IR temperature measurement and color recognition systems to systems for dimensional measurements and defect detection.

Sensors for medical technology, pharma & biotech

Sensors and measurement technology are increasingly used in the growth sectors of medical technology, pharmaceuticals and biotechnology, where they improve quality and efficiency in a sustainable way. As a competent partner for these industries, Micro-Epsilon is constantly developing new measurement solutions. This brochure provides an overview of some successfully implemented solutions.

Partnerships with customers


With above-average R&D activity, strong expertise and a large network of cooperation partners, we create innovative sensor products with the highest precision. Partnerships are essential in achieving such levels of excellence. Therefore, we understand that our customers are our business partners, which is a win-win situation for both parties.

Position measurement in X-ray devices

Task: Aligning the X-ray tube to the camera

Solution: Position measurement of all moving components for the synchronized control of the X-ray machine

Sensor: wireSENSOR



Advantage:
Perfectly aligned technology
for ultra-sharp images



Projection position of mammography devices

Task: Automatic approach of projection positions for certain images

Solution: Displacement measurement of the movement in order to use the data for the control system

Sensor: wireSENSOR

Advantage:
Supports the assistant in aligning the mammography device

Positioning of examination couches

Task: Saving and retrieving the sitting and reclining positions

Solution: Integration of sensors into joints for position measurement

Sensor: wireSENSOR



Advantage:

The measuring wire allows for the sensors to be positioned in the couch as desired.



Position of the operating microscope

- Task: Absolute movement correction of the microscope
- Solution: Integration of high-resolution capacitive sensors which detect the change in position
- Sensor: capaNCDT sensors

Advantage:
High visual stability of images
during the operation

Positioning of CT tables

Task: Position measurement of the CT table for 3D reconstruction of images

Solution: Integration of high-resolution draw-wire sensors into the CT table

Sensor: wireSENSOR

Advantage:

Any 3D section can be created with the volume data set.



Angular position of the robot assistant

Task: Support the surgeon in minimal invasive procedures

Solution: Automatic movement of the endoscope on the robot assistant

Sensor: wireSENSOR

Advantage:

The sensors are X-ray-neutral and mounted below the OR table.




Detecting the diameter of stents

Task: Quality assurance of stents after production

Solution: Random diameter and wire inspection of the stents

Sensor: confocalDT sensors



Advantage:
The exact wire thickness
ensures function and
quality of the stents.

Mesh structure of stents

Task: Internal inspection of the stent mesh
Solution: Endoscopes perform a visual inspection
Sensor: Eltrotec Endoscope



Advantage:
Checking the stents
for burrs and structural
distortions

Measurement of dental implants


Task: Inspecting the chewing surfaces of dental implants and checking for wear

Solution: High-resolution digitization of the implant using a displacement sensor

Sensor: confocalDT sensor



Advantage:
Up to four implants can be
scanned simultaneously





Quality monitoring of arch wires

Task: Inspection of the orthodontic wire after automatic bending

Solution: Contour inspection across three axes with micrometers

Sensor: optoCONTROL ODC optical micrometers

Advantage:

Shorter treatment time due to perfectly bent arch wires

Foil temperature in the dental thermoforming unit

Task: Detecting the temperature of the dental foil for thermoforming

Solution: Non-contact temperature measurement of the foil using infrared sensors

Sensor: OEM temperature sensor thermoMETER SE



Advantage:
The miniature sensor hardly affects the design of the device



Movement measurement in rehab and fitness equipment

Task: Logging the movement of the device

Solution: Displacement measurement and counting of the movement

Sensor: wireSENSOR




Advantage:
Training log for optimal results

Inserting needles into cannulas

Task: Determining the ideal time to glue the needle into the cannula

Solution: Temperature monitoring with infrared sensors

Sensor: thermoMETER temperature sensors



Advantage:
Firm fit of the needle in
the cannula

Color assignment with cannula holders

Task: Assign the cannula holder to the correct cannula diameter

Solution: Color measurement of the cannula holder during production

Sensor: colorSENSOR



Advantage:

Automatic sorting of parts
during production




Detection of the infusion tube thickness

Task: High quality due to consistent tube wall thicknesses

Solution: Layer thickness measurement using a non-contact sensor

Sensor: confocalDT sensor





Advantage:
Only one sensor is required to
check several tube layers

Level measurement in the microtiter

Task: Precise dosing during automatic pipetting of microtiters

Solution: Micron-precise filling level measurement using a confocal sensor

Sensor: confocalDT sensor





Advantage:
Measurement of all
types of liquids

Contour of glass capillaries

Task: Quality assurance of glass capillaries

Solution: Diameter and layer thickness
inspection of glass capillaries

Sensor: confocalDT sensor



Advantage:


Measuring and classifying several layers
using only one sensor

Measuring the diaphragm thickness

Task: Functional assurance of the diaphragm for LVAD pumps

Solution: Non-contact thickness measurement during production

Sensor: confocalDT sensor



Advantage:
Consistently high quality and
service life of the diaphragm

Checking the wear of tablet presses

Task: Constant compression of the pressed tablets
Solution: Displacement measurement system integrated in
the tablet punch to check the wear of the punch
Sensor: optoNCDT laser sensor

Advantage:
Precise determination of the
system's maintenance intervals to
save costs



Detection of the tablet size

Task: Monitoring the tablet size during production

Solution: Height measurement and classification of pressed tablets

Sensor: optoCONTROL ODC optical micrometer



Advantage:
Constant tablet size over
long periods of time

Testing the active ingredients of tablets

Task: Constant distance between the Raman microscope and the tablet

Solution: Precise surface topography of the tablet using a confocal sensor

Sensor: confocalDT sensor



Advantage:
The high resolution enables to keep a constant distance between microscope and tablet.



Foreign bodies in the tablet packaging process

Task: Recognition of foreign bodies between the blister layers

Solution: Recognition of tablet fragments and foreign bodies, rejection of defective blisters.

Sensor: Magneto-inductive mainSENSOR

Advantage:

A lever directly detects the foreign bodies



Tablet color detection

Task: Sorting tablets for the correct packaging

Solution: Color check of the tablets before packaging

Sensor: colorSENSOR

Advantage:

Identification and rejection of faulty items



Temperature measurement of batteries

Task: Monitoring the temperature of high-performance batteries

Solution: Non-contact temperature sensor for monitoring the battery assembly

Sensor: thermoMETER temperature sensor

Advantage:

Prevents the production and delivery of defective batteries


Sensors and Systems from Micro-Epsilon



Sensors and systems for displacement, distance and position



Sensors and measurement devices for non-contact temperature measurement




Measuring and inspection systems for metal strips, plastics and rubber



Optical micrometers and fiber optics, measuring and test amplifiers



Color recognition sensors, LED analyzers and inline color spectrometers



3D measurement technology for dimensional testing and surface inspection

More Precision

Whether it is for quality assurance, predictive maintenance, process and machine monitoring, automation or R&D – sensors from Micro-Epsilon make a vital contribution to the improvement of products and processes. High precision sensors and measuring systems solve measurement tasks in all core industries – from machine building to automated production lines and integrated OEM solutions.



www.micro-epsilon.com